

# TECH NOTE :: QuantumX / SomatXR Integration into CANape

Version: 2020-08-05 Status: public

## Abstract

This Tech Note describes how to integrate QuantumX / SomatXR into CANape set up as XCP master via standardized xCP-on-Ethernet.

#### System Setup Preparation

You will need:

- latest version of the free HBM Software MX Assistant software
- CANape software from Vector
- QuantumX / SomatXR MX modules and CX27C (-R) gateway module supporting XCP-on-Ethernet

Hint: As we constantly improve, please always keep your embedded and PC software up to date.

This demo shows the QuantumX Universal Amplifier MX440B with a force and a displacement sensor connected. Connect all MX modules via KAB272 to CX27C and then connect your PC to CX27C by Ethernet cable.





## Workflow

# **MX** Assistant Setup

Start MX Assistant and search the network for available modules (press F4). Select CX27C and confirm with 'OK'.



Go to "Signals" tab and select all signals and activate isochronous data transfer.

8725 🛛 🎪	🔜 - 🕝 🕐							
File	Channels S	ignals Func	tions Ou	Itputs		Scope	Senso	r database
Settings	ISO Activate isoci 190 Deactivate is	hronous data tra ochronous data	transfer Co	py Paste	Options •			
Modules		Signal		4			_	
Name	-	Serial / UUID	Sync. type			Path		
	Computer				1.1 : MX	(440B (005E	EC)	Travel
<b>⊡</b> - (	CX27C	00B0F7	Auto (Fire)	Vire)	2.1 : MX	(440B (005E	EC)	Force 1
ι	- 🥥 🐹 MX440B	005EEC	Auto (Fire)	Vire)	3.1 : MX	(440B (005E	EC)	MX440B_CH_3
					4.1 : MX	(440B (005E	EC)	MX440B_CH_4



89%   歳 🔜 🔹	1									
File Cha	nels Si	ignals	Functi	ons Qutputs	Digi	tal I/Os	Scope S	ensor databas	e	
Assign Options	- Details	Edit	Ø Details	Type • PROFIN	ET *	xCP Ethernot	v ✓ ✓ ✓	Active	N/A	
Source	Cha	innel		Con	necto	or		CAN bus-	load monitoring	
Modules				P	V	Analog	# PROFINE	xCP XCP on	Ethernet	
Name		Serial /	UUID	Sync. type				-		
🖃 🥥 🔜 Com	puter						Path	Туре		
i- ● 🔎 (	X27C	00B0F7		Auto (FireWire)		1.1 : CX	27C (00B0F7)	Off	AnalogIn_Connecto	or1.Signal1
hun 🍑 🏿	MX440B	005EEC	:	Auto (FireWire)						

Go to Outputs (1) and XCP on Ethernet (2) tab and activate XCP on Ethernet (3).

Drag-and-drop the available signal sources to the XCP-on-Ethernet signal collector.

Modules		<del>q</del>	V A	nalog #PROFINET	XCP on Ethernet	
Name	Serial / UU	JID Sync. type		Path	Turne	
🗉 🥥 🔜 Computer				1 dui	TYPE	
Ē-   ♥ CX270	00B0F7	Auto (FireWire)		1.1 : CX27C (00B0F7)	XCP on Ethernet	1.1.1: Travel / MX440B (005EEC) (isochronous)
🔾 🗮 MX	440B 005EEC	Auto (FireWire)	1	.2 : CX27C (00B0F7)	XCP on Ethernet	2.1.1: Force 1/MX440B (005EEC) (isochronous)
			1	1.3 : CX27C (00B0F7)	XCP on Ethernet	3.1.1: MX440B_CH_3/MX440B (005EEC) (isochronous)
			1	.4 : CX27C (00B0F7)	XCP on Ethernet	4.1.1: MX440B_CH_4/MX440B (005EEC) (isochronous)
				.5 : CX27C (00B0F7)	XCP on E	
			1	.6 : CX27C (00B0F7)	XCP on P	
			1	.7 : CX27C (00B0F7)	XC	
			1	.8 : CX27C (00B0F7)	riernet	
Sources			1	.9 : CX27C (00B0F7	on Ethernet	
Show only	isachronous		1	1.10 : CX27C	XCP on Ethernet	
Show only	isocinonous		1	I.11 : CY	XCP on Ethernet	
Show all n	nodules		1	.12 60F7)	XCP on Ethernet	
Expa	nd all	Collapse all		C (00B0F7)	XCP on Ethernet	
E Scomputer			10	CX27C (00B0F7)	XCP on Ethernet	
B P CX27C (008	0F7)		suc	.15 : CX27C (00B0F7)	XCP on Ethernet	
B- ₩ MX440B	(005EEC)	Orab		.16 : CX27C (00B0F7)	XCP on Ethernet	
- ③ 1.1.1	Travel (isochron	ous)	1	.17 : CX27C (00B0F7)	XCP on Ethernet	
- \$ 2.1.1	Force 1 (isochro	nous)	1	.18 : CX27C (00B0F7)	XCP on Ethernet	
- <u>V</u> 3.1.1	: MX440B_CH_3	(isochronous)	1	.19 : CX27C (00B0F7)	XCP on Ethernet	
<u> </u>	: MX440B_CH_4	(isochronous)	1	.20 : CX27C (00B0F7)	XCP on Ethernet	
					WOD DI	

Export your setup to an ASAM MCD-2 MC / short A2L database file in the xCP Ethernet dropdown menu and save it.





# CANape Setup

Start CANape and create a new measurement project. To integrate the QuantumX modules, go to 'Devices' choose 'New From Database' and select your A2L file.

Start Display	Devices	← → ∽ ↑ 🔚 > Dieser	PC > Desktop	~ Ü	"Desktop" durchsucher	م ا
		Organisieren 👻 Neuer Ord	ner			. ?
Device w New Fr onfiguration Device Databa	om New \ ase From + Ha	Roaming ^ Nam	e		Änderungsdatum	Тур
New	/	🔎 Suchvorgär	Download		22.07.2020 09:41	Dateiordne
umbol Evolorer	a ×	🖀 Videos 📜	bld		29.07.2020 14:58	Dateiordn
ymbor explorer	+	S Dieser PC	Prerequisites		29.07.2020 11:08	Dateiordn
All	~	📙 3D-Objekte 📃 🚺	Programme		25.04.2019 11:02	Dateiordn
3	∨ ab* +	🐌 Bilder	feam Manipal Racing		14.01.2020 13:12	Dateiordn
		🚡 Desktop	x27c_2020-07-29_12-09-17.a2l		29.07.2020 12:09	A2L-Datei
		🕒 Dokumente				
		🔈 Downloads				
		🐌 Musik				
		B Videos				
		II & Suttom (Ci)				

Go through the menu by clicking 'Next'. Create a new network (1) and close window and accept changes (2). Continue going through the menu by clicking 'Next<sup>®</sup> and close the following window tike (2): Abbrechen

	1	
TransportLayer Type Ethernet	Settings for ETH_Ne	twork_1
Show supported layers only	▲   そ も	
Transport Layer Instances	តិត General	General
Network settings		Network
Networks:		Name
New preconfigured network New net	work	Chan
Channel		Commu
visuintu.		Secur

Then go to 'Start' and select 'Signals' in the drop-down menu 'Measurement Configuration'.



In the Measurement Configuration double click your a2l.-file (1), click 'AllSignals' (2), select the signals you need (3) and click 'Apply' (4).





Now go to 'Display', right click in the page (display window), select 'Measurement windows' and 'Graphic window', to create a measurement window, as shown below.



Then press 'F8', to insert a measurement signal. Select you signals and click 'Apply' and close the window.

🗶 🗠 🕸 🕸 🖄 📩 🗶	Appl	y	5	<b>† +</b>	fn 💾	- 🗹 💈		No label list>		
<ul> <li>Measurement options</li> <li>Measurement signals</li> <li>Measurement signals</li> <li>Measurement signals</li> <li>Global Variables</li> <li>Objects</li> <li>Algebraic expressions</li> <li>Stimulations</li> <li>Multimedia signals</li> </ul>	No. 1 2 3 4	Ty	Act	Name Force_1 MX4408 MX4408 Travel	3_CH_3 3_CH_4			Measur 10 Hz 10 Hz 10 Hz 10 Hz	Rate	Re
<ul> <li>Algorithms</li> <li>Algorithms</li> <li></li> <li>Insert search mask he</li> <li>Distributed Recording</li> <li>Recorder list</li> <li>Event list</li> </ul>										
<ul> <li>Algorithms</li> <li>Algorithms     <li>Algorithms     <li>Algorithms     <li>Instributed Recording     <li>Execorder list     <li>Event list     <li>Audio outputs     </li> </li></li></li></li></li></li></ul>	Grap	hical v	ńew	+ (		00.0 %	Search	1		

## Measurement

Now you can start a measurement by pressing 'Start'. It might be useful to scale the Y axis by scrolling on it, in order to display your signal properly.



Hint : To start your measurement you need enough internal memory. Therefore, the page name at the bottom on the right needs to be clear. Closing other programs will help. If it looks like the picture below, it won't work.

Online	(NEW)	

#### -- end

Legal Disclaimer: TECH NOTEs from HBK are designed to provide a quick overview of a specific topic beside the usual documentation. TECH NOTEs are continuously improved and so change frequently. HBK assumes no liability for the completeness of the descriptions. We reserve the right to make changes to the features and/or the descriptions at any time without prior notice.

