

TECH NOTE :: QuantumX Real-Time Processing and Outputs

Version: 2014-04-25 Author: Christof Salcher, Product Manager Test & Measurement, HBM Germany Status: public

Intro

QuantumX is a modular distributable data acquisition solution from HBM for measurement and testing solving demanding engineering tasks for quicker innovation. The data acquisition modules offer highly accurate inputs acquiring physical quantities in the wide field of **mechanical**, **hydraulics**, **thermal** and **electrical or mixed systems** with data rates from 0.1 to 100 kS/sec and channel. QuantumX acquires sensor or transducer inputs measuring **force**, **strain**, **torque**, **pressure**, **temperature**, **displacement**, **speed**, **position**, **acceleration**, **flow**, **voltage**, **current** and **many more**. QuantumX offers superb A/D inputs supporting **voltage**, **current**, **bridge based inputs for strain gage or inductive transducers**, **LVDT**, **resistive**, **thermocouple**, **digital pulses** and signals from data busses like **CAN bus** parallel and time synchronous to all other inputs.

Some modules have output capability and work as signal converter (input to output), signal generator, real-time reaction (analog, digital) or gateway to other digital busses then Ethernet or FireWire like CAN bus or EtherCAT bus.

Abstract

This TECH NOTE shows in principle how to work with real-time processing and signal outputs in the QuantumX series.

First of all it's good to understand the principle philosophy of the QuantumX signal data path.

Every QuantumX module has got two bus interfaces – Ethernet and FireWire

FireWire can be used for

1) asynchronous data transfer from a source (input) to a sink (PC or Data Recorder)

2) isochronous real-time data transfer routing signals to real-time processing units or outputs

3) automatic time synchronisation of all modules and channels

4) power distribution from module to module or hub with a maximum of 1.5 Ampere from node to node (rule of thumb: 3 modules over FireWire than new power supply with same voltage level or same source).





The following graphic shows in principle the complete data flow from input to output:

All inputs or in general "signal sources" can be split into two signals for different purposes:

- **Standard Signal**: with max datarate and filter for <u>pure measurement</u> and online PC based analysis
- **Reference or 2nd Signal**: up to 4.8 kHz/ch datarate for <u>isochronous</u> real-time data transfer over FireWire for real-time operation, analysis and output.

Parameterization can be done with the software QuantumX Assistant, LabVIEW or from your own application which includes the QuantumX application programming interface (.NET API).

QuantumX Assistant is a for free non programming application you can find on the QuantumX System CD or for download. This tool can easily parameterize:

- inputs to outputs (analog / digital / CAN → analog / digital / CAN / EtherCAT)
- signal generator as analog voltage output (harmonic pre-defined signal or file based free creation)
- real-time operation

A signal source can be a measurement input or a result of a math operation. Some QuantumX modules support mathematics, analysis or output functionality in real-time. Some outputs can be controlled via PC which brings us to the differentiation between <u>real-time</u> and <u>online</u>.

Real-Time: deterministic, fix time latency, no time jitter, fast response in some micro or milliseconds **Example for Real-Time**: force sensor on MX840A channel no 1 -> asynchronous 1st signal with 19.2 kS/sec 2 kHz filter to PC for data acquisition / isochronous 2nd signal with max. 4.8 kHz and a respective filter for example 200 Hz -> MX879 picks up isochronous signal and is parameterized to do a limit switch math operation (200 Newton, active LOW, hysteresis - 10 N) -> MX879 digital output 1 switches to HIGH (24 V) when 200 N limit is reached, falls back if lower than 90 N. Time latency between input and output is approximately 2 ms.

Online: PC based, response in some milliseconds, varying time latency

Example for Online: force sensor on MX840A channel no 1 -> 1st signal asynchronous data transfer over Ethernet to PC - > catmanEASY / LabVIEW / .NET application parameterized to do a <u>limit switch math operation</u> (200 Newton, active LOW, hysteresis - 10 N) -> asynchronous data transfer to MX879 digital output 1 switches to HIGH (24 V) when 200 N limit is reached, falls back if lower than 90 N. Time latency between input and output is ~ 50 ms.



QuantumX Real-time Operation and Output

The following modules offer outputs:

- MX410/B: real-time operation (RMS, PEAK) and direct analog voltage output
- MX878: real-time math operation and analog voltage output
- MX879: real-time math operation and output (digital 5 or 24 V, analog voltage)
- MX471: send signals to CAN bus
- CX27: send any signal to EtherCAT bus

The modules MX878 (8 analog voltage output) and MX879 (8 analog voltage outputs and 32 digital IO) offer also <u>real-</u> <u>time operation</u>:

- PID control
- Cross calculation Add / Mul with the formula: y = a0 + a1 * Signal₁ + a2 * Signal₂ + a3 * Signal₁ * Signal₂ Simple Addition: a₀ = 0, a₁ = 1, a₂ = 1, a₃ = 0 Simple Multiplication: a₀ = 0, a₁ = 0, a₂ = 0, a₃ = 1
- Matrix calculation 6 x 6 for example to compensate cross-talk of 6 DOF load cells with the formula



- PEAK detection over time or cycle
- Root Mean Square (RMS) calculation over time
- Signal Generator (standard, arbitrary)
- MX879 only: Limit Switch Function / Alarm: Switch on digital output on certain level of *Signal*

The module MX460 (4 channel digital input focusing on speed and torque) offers in addition <u>real-time torsional</u> <u>vibration</u> and <u>angle difference</u> for angle based analysis of shafts or combustion engines.

The outputs of the following modules can be controlled via PC online:

- Example: algebra or logic calculation in catmanEASY activating a digital output on MX879 or an analog output on MX878 / MX879 (timing ~ 50 ms)
- Analog output of MX878 or MX879
- Digital output on CX22-W Data Recorder, CX27 Ethernet / EtherCAT interface or MX879 Multi IO module
- MX440A, MX840A: digital output on every port (pin 15, timing ~ 200 ms)

QuantumX covers use cases like:

- A) Pure mapping of any <u>input</u> to analog voltage <u>output</u> (MX410/B, MX878, MX879)
 - On MX410 drag and drop universal input to direct analog voltage output.
 Example: MX410 with direct voltage out (~ 200 µs time latency)
 - Output signals from any module in the FireWire network to MX878 or MX879, scaled to ± 10 V, with additional low pass filter if necessary.
 Example: all MX840A inputs send to MX879 analog out to be integrated into an existing test stand,
 - MX879 also activates digital outputs when limit is reached in real-time (i.e. over 1 kN)
 - Drag and drop CAN signals from MX471 / MX840A to MX878 / MX879, scaled to ± 10 V, additional filter if necessary.

Example: MX471 CAN bus signals send to MX878 as analog voltage output



- B) Sending any signal to CAN bus (digital gateway)
 - Any signal in the FireWire network can be send via MX471 module as CAN message.
 - Example: analog sensor inputs of MX1615B and MX1601/B, MX410/B input as RMS value and CAN signals of MX471 itself and real-time torsional vibration of MX460 can be send as separate CAN signals via MX471
 - Inputs 2 to 8 on module MX840A can be sent as separate CAN signals on port 1 with 100 Hz datarate per signal.
 - To simply integration on the other side QuantumX Assistant can generate of CAN description file (*.dbc)
- C) sending any input signal to EtherCAT and integrate QuantumX universal inputs in large scale real-time test stands and in parallel over Ethernet to a standard PC with catmanEasy for signal analysis
 - o Any input or calculated signal can be sent to EtherCAT bus in real-time via CX27 EtherCAT slave
 - Example: MX840A (input of load cell, displacement inputs), MX1609 (temperature signals), MX471 (CAN signal input, CCP signal input) send to => CX27 EtherCAT Gateway in real-time and to EtherCAT.
 - o To simplify integration QuantumX Assistant can generate an EtherCAT parameter file (*.esi)
- D) using real-time processing functionality for small scale system test stands
 - Modules like MX878 / MX879 provide real-time processing power which can be easily parameterized
 - Example: MX840A inputs send to MX878 or MX879 working as PID controller with voltage output as control interface
- E) signal generation with MX878 / MX979
 - o Standard Waveforms: constant value, sine, rectangle and triangle with variable frequency / amplitude
 - o Arbitrary mode: load any signal into buffer and replay (up to 10.000 signals)
- F) Analog or Digital Output activation with catmanAP / EASYscript
 - Any input signal cross calculated -> limit switch / alarm monitorin -> digital output activation
 - Any input signal cross calculated -> analog output activation

Important to know: All configurations are stored permanently in the modules. After power down and power up all configurations are active!



A1) Mapping any signal to analog voltage output

Any type of input (analog, digital, CAN) or signal (real-time calculated signal) within the QuantumX system can be mapped to an analog voltage output on MX878 or MX879 and will work right after power up. The PC is only necessary for parameterization.



Step by Step instruction on how to map inputs to outputs with the software QuantumX Assistant The workflow to map any input to an output is shown in example. All other variants follow the same workflow.

1. Set up the overall system





2. Wire up the input and outputs

For this example the following cables are required: 2 x BNC to SubHD 15 pin voltage pinning



A signal generator delivers a 400 Hz sine signal with 1 V amplitude.

Connect the signal generator to **input 1 of MX840A** and parameterize it as 10 V voltage input via sensor database.

Input 1 signal 1 shall be parameterized with 4.8 kS/sec sample rate, no filter and isochronous

Input 1 signal 2 shall be parameterized with a datarate of 19.2 kS/sec, filter = OFF.

Connect output 1 of MX878 to input 2 of MX840A as reference for latency measurement

Parameterize port 1 of MX878 as 0 ... 10 V input = 0 ... 10 V output, filter = OFF

- Parameterize MX840A port 2 as 10 V voltage input via sensor database. Datarate shall be 19.2 kHz, filter = OFF.
- 3. Go to Channels tab: parameterize inputs 1 and 2 as voltage input via Sensor Database

💫 🛕 🖵 - 🔕 🥑		QuantumX Assistant V2.4 F	R2 (113)	_ = 3
Channels Signals Functions Outputs Scope	Sensor database			Show I
Image: Constraint of the state of	image: Series of the serie	CAN Flash Options▼		
Sensors	Zero (Connectors		
todules	Path	Type Signal name	1525 Amplifier setting	Output unit 🥶 Reading
MX878 AnalogOut (001AF8)	1.1 : MX840A (00281B)	A-IN LINE-IN	💵 💆 Voltage; 10.2 V \cdots	V 🗸 -0.003 V 👀
	2.1 : MX840A (00281B)	A-IN Refeed	10.2 Voltage; 10.2 V	V 🔽 -0.002 V 🐽
	3.1 : MX840A (00281B)	A-IN	🌃 👱 Voltage; 10.2 V 🔛	V 💌 »No sensor connected « 🤍
	4.1 : MX840A (00281B)	A-IN	10.2 Voltage; 10.2 V	V No sensor connected « 🥥
	5.1 : MX840A (00281B)	A-IN	102 Voltage; 10.2 V	No sensor connected «
	6.1 : MX840A (00281B)	A-IN	100 Voltage; 10.2 V	No sensor connected « U
	7.1: MX84UA (UU281B) 9.1: MX940A (00291P)	AIN		No sensor connected « No sensor connected «
ensor DB				

4. Go to *Signals* tab: configure datarate, filter and activate **isochronous** data transfer



5. Go to Outputs tab: drag & drop isochronous signal to port 1

à 🖬 - 🛛 🔍	Quantum	X Assistant V2.4 R2 (113)	_ = X
Channels Signals Functions Outputs Scope	Sensor database		Show log
Assign Options • Details Edit Details Type • Options •			
Source Channel Connector			
Modules 7	Analog outputs		
	Path	Type Jam Source	Settings
	1.1 : MX878 AnalogOut (001AF8)	A-OUT LIN 1.1.1: LINE -IN / MX840A (00281B) (isochronous) Vol	tage ; Filter off 🛛 🙀
	2 : MX878 AnalogOut (001AF8)	Off	
	3 : MX878 AnalogOut (001AF8)	Off	
	4 : MX878 AnalogOut (001AF8)	Off	
	5 : MX878 AnalogOut (001AF8)	Off	
	6 : MX878 AnalogOut (001AF8)	Off	
	7 : MX878 AnalogOut (001AF8)	Off	
	8 : MX878 AnalogOut (001AF8)	Off	
Sources 4			
Show only isochronous			
Expand all Collapse all			
Computer			

6. Go to Scope tab: Start measurement





7. Stop measurement and measure time latency.

For latency calculation please refer to modules datasheet and the filter settings.





A2) MX410/B - universal analog inputs to analog voltage output

MX410/B offers direct analog output to every input of the module. Time latency from input to output is min. 250 μ s for max. data rate and filter = OFF.



B1) MX840A - 7 inputs send to CAN bus output (port 1)

MX840A port 1 can be configured as CAN output. The procedure is almost the same like above. Isochronous data mode of the signal is not necessary as they don't go to FireWire. All 7 universal inputs of the module can be sent to CAN bus. It is <u>not</u> possible to send out inputs from other modules via port 1 of MX840A.

QuantumX Assistant is the best tool to map an input signal to a CAN message. The software can also generate a CAN configuration file (*.dbc) which makes integration very easy.



How to parameterize a CAN output?

- 1. Start the software QuantumX Assistant.
- Go to Channels tab: parameterize sensor inputs via Sensor Database (drag & drop) Remember: TEDS simplifies this step – everything is configured automatically right after sensor is plugged in.

🔊 🔍 🖫 × 💋 🔘	Quar	tumX Assistant V2.5 R1 (136)	
Channels Signals Functions Outputs Digital I/	Os Scope Sensor database		Show log
Image: Constraint of the second se	Image: Clear Zero Image: Clear Details Image: Clear Type ▼ CAN F Bus ▼ Zero Connecto Connecto	Ć: ♥ J ED Options ♥	
Modules #	,		
Name Serial / UUID Sync. type	Path Type Signal r	ame Sensor description 1926 Ampli	fier setting put 🤒 Signal value 🔺
	1.1 : MX840A Universal (00: A-IN No name	10.2 Voltage; 10.2	2 V 👻 » No sensor connected « 🖤
MX840A Universal 00281B Auto	2.1 : MX840A Universal (00: A-IN ground for	rce U3_H38287_force-ground 🏻 🌇 🛞 Full bridge; 4	J800 Hz; (5 mV/ 💀 💌 5.530 N 👀
	3.1 : MX840A Universal (00, A-IN No name	10.1 Voltage; 10.1	2 V 💀 💌 »No sensor connected « 🤍
	4.1 : MX840A Universal (00, A-IN No name	40 ¥ Voltage; 10.2	2 V No sensor connected « 🥥
	5.1 : MX840A Universal (00: A-IN No reme	10.1 Voltage; 10.1	2 V 💀 💌 » No sensor connected « 🥥
	6.1 : MX840A Universal (00: A-IN Ko name	10.1 Voltage; 10.1	2 V Vo sensor connected « 🥥
	7.1 : MX840A Universal (00) A-IN No name	Voltage; 10.2	2 V No sensor connected «
	8.1 : MX840A Universal (00: A-IN No name	Tottage; 10.2	2 V Vo sensor connected «
Sensor DB P Databases CAN databases (not editable) HBM sensor databases (not editable) HBM sensor databases (editable) WrSDB.adb WrSDB.a			F
l 🗘			

3. Go to *Signals* tab: configure datarate and filter and name of the signal

Remember: QuantumX can split a single source into two signals – one for example for analysis and another one for realtime purposes with certain limitations. Sending CAN messages over port 1 of MX840A is limited to 100 Hz max datarate per signal. The second signal is named "ground force (CAN bus)" to clearly identify the signal which shall be sent to CAN bus.

🕋 🔍 🔜 - 🐮 🔘	👝 🗽 🐮 🕐 QuantumXAssistant V2.5 R1 (136) 📃 🗖 🔤 💌				
Channels Signals Functions Outputs Dig	ital I/Os Scope Sensor database	•			Show log
Settings 20 Activate isochronous data transfer Copy Pa	ste Options ▼				
Modules 4 Name Serial/UUID Sync type	Path	Signal name	Filter @ Samplerate or CAN signal format: repetition time		Signal value
		No name	Bessel 100Hz @ 1200/s		» No sensor connected « 🕘
MX840A Universal 00281B Auto	1.1: MX840A Universal (00281B	No name	Bessel 10Hz @ 100/s		» No sensor connected « 🕘
	2.1 - MX840A Universal (00281B	ground force	Bessel 100Hz @ 1200/s		5.582 N 🔍
	2.1.10000000000000000000000000000000000	ground force (CAN bus)	Bessel 10Hz @ 100/s		5.547 N 🞯
	3.1 · MX840A Universal (00281B	No name	Bessel 100Hz @ 1200/s	•••	» No sensor connected « 🕘
		No name	Bessel 10Hz @ 100/s	•••	»No sensor connected « 🧶
	4.1 · MX840A Universal (00281B	No name	Bessel 100Hz @ 1200/s	•••	» No sensor connected « 🔍
		No name	Bessel 10Hz @ 100/s	•••	» No sensor connected « 🧶 🗏
	5 1 · MX840A Universal (00281B	No name	Bessel 100Hz @ 1200/s		» No sensor connected « 🔍
		No name	Bessel 10Hz @ 100/s	•••	» No sensor connected « 🔍
	6.1 · MX840A Universal (00281B	No name	Bessel 100Hz @ 1200/s		» No sensor connected « 🔍
		No name	Bessel 10Hz @ 100/s		» No sensor connected « 🔍
	7.1 : MX840A Universal (00281B	No name	Bessel 100Hz @ 1200/s		» No sensor connected « 🔍
		No name	Bessel 10Hz @ 100/s		» No sensor connected « 🔍
	8.1 · MX840A Universal (00281B	No name	Bessel 100Hz @ 1200/s	•••	» No sensor connected « 🔍
		No name	Bessel 10Hz @ 100/s	•••	» No sensor connected « 🔍

4. In Channels tab: parameterize channel 1 as CAN node – Type: CAN Bus

A = 2 0		QuantumX Assistant V2.5 R1 (136)	-	
Channels Signals Functions Outputs Digita	I/Os Scope Sensor database			Show log
Image: Sensor Image:	✓ Zero ⊘ Edat Zero Zero	AN Flash Options -		
Modules 7	Path CAN	Bus Sensor description	Amplifier setting	put 🐵 Signal value
O Computer	1.1 : MX840A Universal (00281B) A-IN	No nan	🍱 🛂 Voltage: 10.2 V 🕞	» No sensor connected «
MX840A Universal 00281B Auto	2.1 : MX840A Universal (00281B) A-IN	ground U3_H38287_force-ground	146 🛞 Full bridge; 4800 Hz; (5 mV/ 🕠	- 5.547 N 🚳
	3.1 : MX840A Universal (00281B) A-IN	No nan	🌇 👱 Voltage; 10.2 V 💽	» No sensor connected « 🥥
	4.1 : MX840A Universal (00281B) A-IN	No nan	🌇 👱 Voltage; 10.2 V 🕞	» No sensor connected « 🥥
	5.1 : MX840A Universal (00281B) A-IN	No nan	🍱 👱 Voltage; 10.2 V 🕞	 No sensor connected «
	6.1 : MX840A Universal (00281B) A-IN	No nan	🍱 👱 Voltage; 10.2 V 🕞	 » No sensor connected «
	7.1 : MX840A Universal (00281B) A-IN	No nan	🌇 👱 Voltage; 10.2 V 🕞	» No sensor connected « 🥥
Senser DR II	8.1 : MX840A Universal (00281B) A-IN	No nan	🌇 👱 Voltage; 10.2 V 🕞	» No sensor connected « 🥥 😑



Parameterize CAN bus settings

a 🖬 - C O	QuantumX Assistant V2.5 R1 (136)		
Channels Signals Functions Outputs Digita	II/Os Scope Sensor database		Show log
Image: Constraint of the state of	v Zero ⊉Edit Details Type v CAN Flash Options v		
Sensor	Zero C Settings		
Modules 4 Name Serial / UUID Sync. type	Path Ty CAN Bus settings Setup CAN Bus parameters of th	Amplifier setting put 🧐	Signal value
E- O S Computer	1.1 : MX840A Universal (00281B) CAN selected module (blue frame in to 1.1 - MX840A Universal (00281B) A IN	able).	<u> </u>
- O281B Auto	2.1 : MX840A Universal (00281B) A-IN ground U3_H38287_torce-ground 3.1 : MX840A Universal (00281B) A-IN No nan	Kontene: 10.2 V Kontene: 10.2 V	5.568 N 08
-	4.1 : MX840A Universal (00281B) A-IN No nan	148 ⊻ Voltage: 10.2 V	» No sensor connected «
	5.1 : MX840A Universal (00281B) A-IN No nan	10.2 V Voltage; 10.2 V	» No sensor connected « 🔍
	6.1 : MX840A Universal (00281B) A-IN No nan	146 Voltage; 10.2 V	» No sensor connected « 🔍
	7.1 : MX840A Universal (00281B) A-IN No nan	🌃 👱 Voltage: 10.2 V 🛛 💀 💌	» No sensor connected « 🥥
	8.1 : MX840A Universal (00281B) A-IN No nan	146 ⊻ Voltage; 10.2 V 💀 💌 💌	» No sensor connected « 🕘
Sensor DB 4			E
			*
ŵ			.::

Modify the parameters according to your needs:

Example: Bit rate: 500.000 bit/sec

Remember: CAN bus has to be physically terminated on both ends of the bus with 120 Ohm. If needed you can solder a termination resistor into the plug.

	CAN Bus settings »00281B«
Specify CAN Bus The settings will b	settings. be set to the module currently selected in the table (blue frame).
For CCP / XCP of will be deactivate re-activation must	ver CAN all CAN transmit messages and all CAN output channels d and can not be changed while in this mode. Afterwards a possible t be done manually.
Bit rate	500000
Supply voltage	0
Standard	
CAN transmit mes	ssages
8 2 🗉	Expand all Collapse all
	messages
CAN transmit CAN transmit me	messages essages
() <u>H</u> elp	<u>O</u> K <u>Cancel</u>



5. Go to Outputs tab: drag and drop signal to "CAN outputs" field

🔊 🔌 🖫 - 🕲 🕲		QuantumX Assistant V2.5 R1	(136)	
Channels Signals Functions Outputs Digital I/O	s Scope Sensor database			Show log
Assign Options* Details Edit Details Type * CAN Bus *	v v ms ▼			
Source Channel Connector				
Modules 7	Analog outputs CAN outputs			
Name Serial / UUID Sync. type	Path	Type Name	Source	Settings
- 🕒 🗮 MX840A Universal 00281B Auto	1.1 : MX840A Universal (00281B)	CAN Bus ground force (CAN bu	2.1.2: ground force (CAN bus)	ground force (CAN bus) (385) 🔐
	1.2 : MX840A Universal (00281B)	CAN Bus		Disabled
	1.3 : MX840A Universal (00281B)	CAN Bus		Disabled
Sources 4	1.4 : MX840A Universal (002818)	CAN Bus		Disabled
Show only isochronous	1.5 : MX840A Universal (02281B)	CAN Bus		Disabled
Show all modules	1.6 : MX840A Universal (00281B)	CAN Bus		Disabled
Expand all Collapse all	1.7 : MX840A Universal (00281B)	CAN Bus		Disabled
	1.8 : MX840A Universal (00281B)	CAN Bus		Disabled
B-X MX840A Universal	1.9 : MX840A Universal (00281B)	CAN Bus		Disabled
2 1 1 anual fame	1.10 MX840A Universal (00281B)	CAN Bus		Disabled E
🚔				

Now click on Settings [...] for message parameterization

CAN	Edit object		x
Edi	it the settings of ground force ((CAN bus).	
	Expand all Co	ollapse all	
	Channel number	0	
	Channel name	ground force (CAN bus)	
	Origin of name	User	
	Active	Enabled	
	CAN transmit message		
	CAN ID	385	Ξ
	Frame format	Standard (11-bit ID)	
	Byte sequence	Intel	
	Transmission divider	1	
	Source		
	Source number	0	
	Description		
	Module reference		-
Ch Ch	n annel number nannel number		
		<u>O</u> K <u>C</u> ancel	.::

6. Optional: generate CAN configuration file (dbc) like shown in the picture – "Export to CAN database file". Remember: this file simplifies integration or parameterization of the receiver.

🕋 🔌 🖬 - 🗶 🔘	C	QuantumX Assistant V2.5 R1 (136)		
Channels Signals Functions Outputs Digital	I/Os Scope Sensor database			Show log
Assign Options - Source Compositions - Channel Composition - Source Composition - Composition - Comp	ŢŢ ptions ▼			
Modules Assi	sign message IDs AN outputs			
Name Serial / UUID Syn Expo	port to CAN database file	Type Name	Source	Settings
Communication Series Se	Export the currently selected	AN Bus ground force (CAN bus)	2.1.2: ground force (CAN bus)	ground force (CAN bus) (385)
	CAN database file.	AN Bus CAN Bus		Disabled
Sources 4	1.4 : MX840A Universal (00281B)	CAN Bus		Disabled
Show only isochronous	1.5 : MX840A Universal (00281B)	CAN Bus		Disabled
Show all modules	1.6 : MX840A Universal (00281B)	CAN Bus		Disabled
Expand all Collapse all	1.7 : MX840A Universal (00281B)	CAN Bus		Disabled
	1.8 : MX840A Universal (00281B)	CAN Bus		Disabled
MX840A Universal	1.9 : MX840A Universal (00281B)	CAN Bus		Disabled
	1.10 : MX840A Universal (00281B)	CAN Bus		Disabled =

B2) MX471 - mapping all kind of signals to CAN bus output

MX471 is a module which can be used as gateway module sending any measurement input or real-time signal to CAN. MX471 is not a CAN-2-CAN gateway. All CAN signals acquired from MX471 are stored in Float data format.



stand alone after parameterization

C) Integrate QuantumX in real-time signal to EtherCAT bus

CX27 is the QuantumX EtherCAT / Ethernet gateway. Mapping of inputs to EtherCAT is the same like described above. In parallel a Data Logger can acquire high-speed data over Ethernet or FireWire.



D) PID control with QuantumX

MX878 / MX879 offer 4 PID controller which can be parameterized with the software QuantumX Assistant or in your own software based on QuantumX .NET / COM API.

The PID control algorithm comprises three elements:

- Proportional also known as Gain
- Integral
- Derivative

PID controllers are typically parameterized in the following **combinations**:

- Proportional only
- Proportional and Integral (most common)
- Proportional, Integral, and Derivative
- Proportional and Derivative

Initial Conditions: setting up initial conditions is relevant for highly dynamic systems.

Coping with Limits: It is prudent to limit the output to a certain range. There can be good reasons for more restrictive limits: amplifiers that are unipolar and can't respond to negative values, systems that respond dangerously fast if driven too hard, etc. Therefore two additional configuration parameters are available forcing outputs to be limited to a specified range.



Avoiding Windup: After limits are applied linear PID controls become nonlinear, and this has some side effects. Consider what happens when a controller starts at a zero state and is commanded to start regulating at a high level. While the controller is driving hard toward the new level, the system is still far away from the target set point, so the integral accumulates rapidly. Eventually, even though the desired output level is reached, and passed, the integral effects by themselves are enough to continue driving ahead at maximum. This behaviour is known as windup, and the extended transient time required to correct the integrator imbalance is known as unwinding. Various strategies to counter windup effects are known collectively as anti-windup.

Functional PID description

Function	Quasi-linear PID controller with parallel structure and anti-windup
	$Kp * (1 + \frac{1}{Ti * s} + \frac{Td * s}{Tp * s + 1})$
	Tp is the parasitic time constant, see below
Max amount of function blocks pe module	r 4 from in total 4 Math Units running on MX878 / MX879
Max. turnaround time /	1200 Hz / \sim 1 ms (ATTENTION: input datarate and ouput datarate + filter are
Output rate	additional tuning factors which are still flexible.
Inputs	- Input in0 set point value
	 Input in1 actual value (process value, feedback)
	- Logical Enable input (digital, PC side: ON / OFF, output goes to steady state
	and needs default value parameter)
Outputs	Controller output out0, can be named Actuator and be mapped to analog
	voltage output or / and send in real-time to FireWire bus and then to CAN or EtherCAT
Parameters	Gain Kp, P component
	Reset time Ti [seconds], I component
	Rate time Td [seconds], D component
	Upper limit of the controller output ymax
	Lower limit of the controller output ymin
	Additional value input: as fix output value
	Default output: default is output when Enable input = low
Segmentation Selection	Set by actual value in certain range
Activation / Deactivation	Set by control (any digital input, software control):
	PID is then in halt position and does not integrate any further.Output is freezed to default value
Default	Кр = 0.0



	Ti = 1e38 s
	Td = 0.0 s ymax = 1e20 ymin = -1e20
	enabled = constant High, i.e. permanently active
	default = 0.0
Exception handling	If at least one of the inputs is invalid (Invalid bit),
	 the output is frozen and also marked as invalid the controller is stopped
Integrated Plant Model	Integrated PT1 and PT2 models which can be used as test control plant

The controller cannot be used as mere P controller because of recursive calculation. An I component should always be present.

Parasitic time constant
$$Tp = \frac{1}{a relevant time respectively}$$

$$p = calculation rate$$

 $Tp = \frac{1}{19200}s = 52 \ \mu s$ Default

Segmented parameterization

A "segmented parameterization" corresponds to a set of P, I, D parameters, which will be auto selected from the PID controller's measurement feedback sensor if not tied here. A segmented allows for higher level test scripts or cycles or PLC's to force the selection of the P, I, D parameters independently from the PID controllers measurement feedback sensor.

Example:

- From -inf to 0:
 - P will be 0,05
 - o I will be 0,8
 - o D will be 0
- From 0 to +_:
 - o P will be 0,1
 - o I will be 1
 - o D will be 0

The "beginning" and "end" parameters are the segment boundaries (same as "span" in the segment table).

The "range input" parameter is currently not used.

You can create any number of segments. If not forced by the segment selection input on the previous window, then the segment selection will be automatic, decided from the PID regulator's measurement feedback sensor. This feature is extremely valuable, because it allows for fast rough cut approach to the

target set point, then soft landing. The "saturation" parameters allow clipping the PID regulator's actuator outputs (in absolute range; in the physical unit of the set point, so in bars in our example).



Stabilization

The "stabilization" parameters allow defining the % range around the target set point, where the PID controller is considered stable. In the case above, the PID will be considered stable when the measurement feedback is between 95 and 105% of the set point. A time period parameter is lacking here: we will shortly add this, in order to consider the PID stable only after it has stayed in the stable range for x amount of time.

As the stabilization parameters are defined in % of set point, around zero they have no meaning (because

95% of zero = 105% of zero = zero). So the "dead band" parameters allow defining an absolute stabilization criterion, in the form of a dead-band around zero, in absolute range; in the physical unit of the set point, so in bars in the example above. If the "fixed command" parameter is checked, then the PID will not modify its actuator output when it is stable.

E1) MX878 or MX879 working as signal generator with analog voltage output

Analog voltage outputs of MX878 or MX879 can be parameterized as signal generator with the following signal types

- Constant: i.e. 5 V, this value can also interactively loaded from the PC software side
- Periodic: rectangular, sine, ramp with a certain amplitude and frequency
- Arbitrary: loaded profile in ASCII format from PC side into buffer and replay (up to 10.000 signals) Please go to chapter D2 below for more details.

Parameterized outputs will work right after power up and don't need PC connected.



Step by Step parameterization with QuantumX Assistant

Author: Christof Salcher

- 1. Start the software QuantumX Assistant. Search and configure modules (automatic: DHCP/APIPA)
- 2. Go to Outputs tab of MX878 or MX879 amplifier and parameterize signal generator by right mouse click

- 🕋 🛝 🔙 + 🤣 🕲)			QuantumX Assistant V2.6 R1 (144)			- x
Channels Signals Functions Outputs Digital I	Os Scope Sensor database					Show log
Assign Options*						
Source Channel Connector						
Modules 7	Analog outputs					
Name Serial / UUID Sync. type		_				
B- O 🔤 Computer	Path	Туре	Name	Source	Settings	
- O 🛤 MX879 0035BD Auto	1.1 : MX879 (0035BD)	A-OUT	No name		Voltage ; Filter off	
	2 : MX879 (0035BD)	Off		Edit signal generator		
	3 : MX879 (0035BD)	Off		X Remove source		
	4 : MX879 (0035BD)	Off				
	5 : MX879 (0035BD)	Off				
	6 : MX879 (0035BD)	Off				
	7 : MX879 (0035BD)	Off				
	8 : MX879 (0035BD)	Off				

3. **Enable** signal generator, select **Periodic** type, waveform, frequency, amplitude level (here 10 V), duty cycle and activate or deactivate isochronous data transfer (i.e. sending generated signals out on CAN bus over MX471)





💯 Edit signal generate	r 00358D.1.1: No name	- • •
Edit signal generator		
Expand all Collapse all]	
Signal generator number	0	
Active	Enabled	
Active signal generator type	Periodic	
Settings		
Waveform	Rectangle	
E Amplitude		
Active amplitude type	Level	
Settings		
Low level value	0	
High level value	10	
Frequency in Hz	100	
Duty cycle in %	50	
Signals		
Sionals		
Signals of this signal generator function		OK Cancel

4. Name this output according to its task

🕋 🚴 🔙 - 😕 🕐		QuantumX Assistant V2.6 R1 (144)		
Channels Signals Functions Outputs Digital	/Os Scope Sensor database			Show log
Assign Options • Details Edit Options •				
Source Channel Connector				
Modules	¹ <u>⊻</u> Analog outputs			
Name Serial / UUID Sync. type 	Path Type	Name	Source	Settings
- O 🛤 MX879 0035ED Auto	1.1 : MX879 (0035BD) A-OUT	Signal Generator Rectangular	SG.1: No name	Voltage ; Filter off
	2 : MX879 (0035BD) Off			
	3 : MX879 (0035BD) Off			

E2) MX878 or MX879 working as profile generator with analog voltage output in arbitrary mode

All analog output channels of MX878 or MX879 can generate any signal when working in arbitrary mode. In this mode a file in ASCII format hosting maximum of 10.000 samples is loaded from the PC side to the channel. So it is possible to **replay acquired data** or any designed profile like sweeps or steps to stimulate the system under test.

Every analog voltage output has two buffers this size and can be parameterized with amplitude, frequency, repetition, start, stop, playback, time and switch to second buffer.

Parameterization is done in the same way like D1 above. Just select **Arbitration** type if you want to **load a specific signal** to an output for example to replay a measured input signal.

DEMO EXAMPLES

Files can be loaded over two ways and both are available as demo:

- 1) Microsoft Excel with macro based on QuantumX ActiveX / COM API
- 2) C#.NET demo with QuantumX .NET API.

Both demos are part of the QuantumX System CD: http://www.hbm.com/en/menu/support/software-firmware-downloads/data-acquisition-systems/quantumx/

Parameterized outputs will work right after power up and don't need PC connection.







F) Evaluating inputs in the PC software, cross calculating signals and activating outputs

catmanEasy is a PC based software running on Microsoft Windows and can take over non real-time critical jobs with update rates up to \sim 50 ms. We speak about online instead of real-time!

MX879 offers 8 analog outputs and 32 digital input / outputs.

catmanAP is a professional DAQ software from HBM which allows:

- general online scientific math
 - o basic algebra

•

- o statistics: class counting, min / max, mean, RMS
- o integral, differential
- o filter box / phase correction
- o trigonometric function, logic, ,
- structural durability testing math
 - o rosette calculation: resulting strain, angle
 - o cycle counter
 - o vibration analysis in frequency domain
- powertrain / drivetrain math
 - o angle based statistics: min, max, peak-to-peak

Examples using catmanEasy to activate outputs:

- Logical combination of digital inputs activating digital outputs (AND, OR, NOR, NOT combination) on MX879
- Generating a voltage output signal with MX878 / MX879 by a script (Easy Script license necessary)
- Cross calculating analog inputs to each other (algebra), evaluate certain limits and switch on a digital output on MX879.
- Many more...

Please use the online help of catmanEasy/AP for any further information.