

Firmware Upgrader cannot upgrade LIBERTY

Introduction

HBM usually has LIBERTY users upgrade the firmware (internal software) of their LIBERTY hardware using the HBM firmware upgrader. We recently discovered that there is a bug in the 6.0 through 6.04 versions of firmware that prevents the hardware from successfully upgrading to newer versions. That is why you received a warning message when you tried to run the firmware upgrader and were told to consult this TechNote.

To correct this problem, you will need to manually upgrade LIBERTY's firmware using a Compact Flash card. Once done you must proceed with the normal upgrade process. This TechNote describes the process. Read through it carefully before you start.

If you have questions or problems, contact your local technical support team:

Europe, India and Australia: support@hbm.com

Everywhere else: support@usa.hbm.com

Upgrade recovery for your LIBERTY firmware

Requirements


- A LIBERTY compatible Compact Flash (CF) card with a capacity of at least 32 MB. This card needs to be formatted in the FAT16 format using your PC. You cannot use the standard (FAT32) LIBERTY data CF cards.

Note that many CF cards that come pre-formatted for use in digital cameras and other recording devices use a special proprietary low level format that is not compatible with Liberty. If you are not sure on how to format the card contact your IT department.

- The file named **vxWorks**
 - This file must be extracted from the compressed **Recovery.zip** file that is located on your install CD in the LIBERTY folder, or ...
 - you can download this file from:
<http://www.hbm-test.de/perception/Updates/Liberty/Recovery/Recovery.zip>

Preparation


1. Copy the file **vxWorks** into the root of the CF card
2. Power down the LIBERTY
3. Insert the CF card in the left-hand CF card slot as seen from the front. Refer to the following image for the location of the CF cards.



Copy the file

To copy file into the LIBERTY memory proceed as follows:

1. Power up the LIBERTY
2. When the LIBERTY is booting (starts up) press the keys **Trig**, **Sel** and **Arrow down** simultaneously for a second.





The LIBERTY will now load the file to its internal memory and start up.

Upgrade as usual

Without removing the CF card, it is essential that you now continue with the normal upgrade process:

3. Check the network settings of the mainframe to be sure Liberty is configured correctly for your local connection.
4. If not already done connect your LIBERTY with the PC
5. Start the Firmware Upgrader if it doesn't happen automatically
6. Start the upgrade as usual with the latest firmware version
7. After the update is complete, select "Finish" and wait for the software to close. If your LIBERTY is new enough, it will reboot automatically. If the firmware upgrader software closes and the mainframe has not rebooted, you will need to reboot it manually.
8. When done your LIBERTY has the latest firmware installed. If the upgrade was successful, the front panel will display 6.06.9337.

Head Office

HBM
Im Tiefen See 45
64293 Darmstadt, Germany
Tel: +49 6151 8030
Email: info@hbm.com

Germany

HBM Sales Office
Carl-Zeiss-Ring 11-13
85737 Ismaning
Tel: +49 89 92 33 33 0
Email: info@hbm.com

France

HBM France SAS
46 rue du Champoreux, BP76
91542 Mennecy Cedex
Tel: +33 (0)1 69 90 63 70
Email: info@fr.hbm.com

UK

HBM United Kingdom
1 Churchill Court, 58 Station Road
North Harrow, Middlesex, HA2 7SA
Tel: +44 (0) 208 515 6100
Email: info@uk.hbm.com

USA

HBM, Inc.
19 Bartlett Street
Marlborough, MA 01752, USA
Tel : +1 (800) 578 4260
Email: info@usa.hbm.com

PR China

HBM Sales Office
Room 2912, Jing Guang Centre
Beijing, China 100020
Tel: +86 10 6597 4006
Email: hbmchina@hbm.com.cn