TECH_NOTE::WTX110_Connection_to_the_remote_display

Version: 15/11/2021
Author: Michael Guckes, Patrick Schöpper
Status: HBM: public

Brief description

This application example demonstrates how a value is transferred from the WTX110 to a remote display. For this, the Ethernet interface (M12 connector) on the WTX110 must be implemented on the 2 output from the right. The external control is made possible by a connection to a PC, that using the software tool PanelX. Any device with an Ethernet interface is suitable for this application example.

Hardware configuration

UNRESTRICTED

Connection to the remote display

1. Search for the remote display.
2. If the remote display still has a non-compatible IP address, assign a suitable one via DHCP.
3. Enter the IP address of the remote view under Web Configuration.
4. Confirm.
5. A new Window open: Username: admin / Passwort: emty

Click on connection and the follow window appears:

UNRESTRICTED

Fill in the IP-address of the connected WTX110.

Ab hier weiter übersetzen

Ihre “Connection Settings“ sollten aussehen wie auf dem Bild, außer dem Feld “Remote Host“.

Für die nächsten Einstellungen wird die Konfigurationssoftware des Herstellers benötigt. In unserem Fall die Software des rinstrum D841.

Legal note

These examples are for illustrative purposes only. They are not subject to any warranty or Liability claims.

UNRESTRICTED