------

# RELEASEnotes

### **FASTpress Suite**

Thank you for choosing HBM's Process-Controller series MP85A. and the related software FASTpressSuite.

Your feedback is important for HBM. If you encounter any problems or suggestions to improve the FASTpressSuite software, please let us know.

You can contact our team of support engineers directly at http://www.hbm.com/support

PME-Assistant and PME-Firmware-Loader is available as free download on www.hbm.com/support .

\*\*\*Please download the FASTpress Suite-CD to get the latest Software and Applications.\*\*\* http://www.hbm.com/en/menu/support/software-firmware-downloads/industrial-amplifiers/

#### **Version Overview**

### FASTpress Suite - CD V152

#### PME-Assistant (Version: 3.4.R208)

No news

#### PME-Firmware Loader V1.1.7

No news

#### NEW EASYteach (Version: 1.0.5.10)

No news

#### MP85A-Toolkit V.1.0 R5.12

No news

#### EASYmonitor CE V.1.1 R1.1:

No news

#### I-P.M. data conversion V1.1:

No news

#### NEW INDUSTRYmonitor (Version: 1.2.1.22)

**Bug-Fixes:** 

Graphics of Tolerance-windows corrected, who are relative in Y-direction to Window2



### FASTpress Suite - CD V151

#### PME-Assistant (Version: 3.4.R208)

• Help-files updated: Don't use evaluation mode "Tolerance band" and "Envelope curve" for processes with returning X-values to prevent wrong evaluations.

#### PME-Firmware Loader V1.1.7

No news

#### NEW EASYteach (Version: 1.0.5.10)

No news

#### MP85A-Toolkit V.1.0 R5.12

No news

#### EASYmonitor CE V.1.1 R1.1:

No news

#### I-P.M. data conversion V1.1:

No news

#### NEW INDUSTRYmonitor (Version: 1.2.1.18)

- New: The User.config file is now stored in the folder C:\ProgramData\HBM The directory C: \ ProgramData \ HBM can be hidden. To enable the display in the Windows explorer, the "Show Hidden Folders" setting must be clicked under "System View / Folder Options" in the View tab.
- Help-files updated: Don't use evaluation mode "Tolerance band" and "Envelope curve" for processes with returning X-values to prevent wrong evaluations.

### FASTpress Suite - CD V150

#### PME-Assistant (Version: 3.4.R206)

No news

#### PME-Firmware Loader V1.1.7

No news

### NEW EASYteach (Version: 1.0.5.10)

No news



#### MP85A-Toolkit V.1.0 R5.12

New: (only internal update for HBM production)

#### EASYmonitor CE V.1.1 R1.1:

No news

#### I-P.M. data conversion V1.1:

No news

#### NEW INDUSTRYmonitor (Version: 1.2.1.10)

New:

Windows 7: start button hidden to prevent unauthorized access

**Bug-Fixes:** 

- Windows 7: bugfix on user-right access
- Windows 7: performance update on graphical display of each dialog (suppresses flicker during change of dialoges))

#### **FASTpress Suite - CD V149**

#### NEW PME-Assistant (Version: 3.4.R206)

New:

 Visualization of mean-values for min/max tolerance-windows in actual and from stored processes (statistic: mean for X and Y has to be activated).



**Bug-Fixes:** 

Text correction for tolerance-windows in sequence evaluation.

#### PME-Firmware Loader V1.1.7

No news

#### NEW EASYteach (Version: 1.0.5.10)

New:

Version suitable now for Win7/ 64Bit OS.

#### MP85A-Toolkit V.1.0 R5.10

No news



#### EASYmonitor CE V.1.1 R1.1:

No news

#### I-P.M. data conversion V1.1:

No news

#### NEW INDUSTRYmonitor (Version: 1.2.1.8)

New:

 Visualization of mean-values for min/max tolerance-windows in actual and from stored processes (statistc: mean for X and Y has to be activated).

**Bug-Fixes:** 

- Smaller Correction in texts and buttons-text.
- Correction of autostart-plugins (was starting twice).

#### FASTpress Suite - CD V147

No news, only small textual changes.

\_\_\_\_\_

#### FASTpress Suite - CD V146

#### NEW PME-Assistant (Version: 3.4.R201)

New:

- Implementation of automatic Peak-CAN-Driver update from versiopn 2.x to version 3.x during the installation. This can be useful, when new new multicore PC's have be blocked after installing the Peak-Can-driver version 2.x.
  - >>Then the PC has to be re-started in the secured-mode with admin-rights and the installation has to be done with this new version.

#### PME-Firmware Loader V1.1.7:

<u>No news</u>

#### NEW EASYteach (Version: 1.0.4.10)

No news

#### MP85A-Toolkit V.1.0 R5.9:

<u>No news</u>

#### EASYmonitor CE V.1.1 R1.1:

No news



#### I-P.M. data conversion V1.1:

No news

#### NEW INDUSTRYmonitor (Version: 1.2.1.2)

No news

-----

### FASTpress Suite - CD V145

#### NEW PME-Assistant (Version: 3.4.R101)

No news

#### PME-Firmware Loader V1.1.7:

No news

#### NEW EASYteach (Version: 1.0.4.10)

No news

#### MP85A-Toolkit V.1.0 R5.9:

No news

#### EASYmonitor CE V.1.1 R1.1:

No news

#### I-P.M. data conversion V1.1:

No news

#### NEW INDUSTRYmonitor (Version: 1.2.1.2)

**Bug-Fixes**:

Overview graphic was frozen after reconnect / powered down of the MP85A modules.

#### FASTpress Suite - CD V144

NEW PME-Assistant (Version: 3.4.R101)



#### New:

- Compatibility to Microsoft Windows 7 (64/ 32 bit)
- Implementation of new PEAK-drivers for CAN, compatible to Windows 7 (64/ 32 bit)
- New Gigasoft graphic-component with advanced speed and graphical bug-fixes
- Visu: IO-curves with light-green background.
- Yellow LED in graphic-window during measurement
- Update of the Online- and PDF-Help files

#### **Bug-Fixes:**

- Start-Button with empty device-list
- At process-no# 0 tolerance window adjustement are now possible
- Elimination of TCP/IP-error-message during write access to SD-memory-card

#### PME-Firmware Loader V1.1.7:

New:

- Implementation of new PEAK-drivers for CAN, compatible to Windows 7 (64/ 32 bit)
- Implementation of Firmware-Blocking-Function for MP85A-Devices with FW2.22 and higher

#### NEW EASYteach (Version: 1.0.4.10)

No news.

#### MP85A-Toolkit V.1.0 R5.9:

New:

Compatibility to Microsoft Windows 7 (64/ 32 bit)

#### **Bug-Fixes:**

Correction of curve-display for the MP85A (DP)-S EASYswitch versions.

#### EASYmonitor CE V.1.1 R1.1:

No news.

#### I-P.M. data conversion V1.1:

New:

- Implementation of engl. Software language
- Smaller graphical corrections
- Update of the PDF-Help files

### NEW INDUSTRYmonitor (Version: 1.2.1.1)

New:

- Compatibility to Microsoft Windows 7 (64/ 32 bit)
- New Gigasoft graphic-component with advanced speed and graphical bug-
- fixes



- Visu: IO-curves with light-green background.
- Different colors of the dialogs when leaving the IM (close IM store PS in no.31 to restart with same settings).
- Update of the Online- and PDF-Help files

#### **Bug-Fixes:**

Start-message stays during the complete software-start-up

Elimination of indication of 'switch Point values' in the table for hap tic-

windows

- Correction of Data-storage into the right sub-folders, when the INDUSTRYmonitor is started and MP85A are already storing data (curves/results); (data-storage did run in a default directory).
- Change from normal Threads to Threadpool to prevent that the PC-memory runs over (Microsoft .Net error).
- Implement IM-Process termination to get a clear closing operation for the IM without having the IM running as background-process.
- If FW delivers a negative process-status (whitch is not valuable), IM stays stabile.
- Improved Form-handling (switch from MULTImonitor to EASYmonitor and back) to prevent a PC-Memory blocking (this caused big loss of performance).
- Fmax and Fmin had wrong number of decimal points.
- IM waits for empty curve-memory in the MP85A to proved data-storage (curves/results) in 2 different directories, when switching to a new directory.
- IM uses advanced command: sdo (2950/40=suppress process-start (also from PLC)) to prevent, that parameter-set-changing collide the right entry and storage of the parameters.
- After change of Parameter set (or Fitting Point in BPM), the new evaluation-Criteria (Tol.Windows or Tol.band) gets indicated and old process-curve is deleted.

**FASTpress Suite - CD V141** 

#### NEW PME-Assistant (Version: 3.3.R102)

New:

- Visu: IO-curves with light-green background.
- Yellow LED in graphic-window during measurement

**Bug-Fixes**:

- Start-Button with empty device-list
- At process-no# 0 tolerance window adjustement are now possible

#### PME-Firmware Loader V1.1.7:

New:

 Implementation of Firmware-Blocking-Function for MP85A-Devices with FW2.22 and higher

#### NEW EASYteach (Version: 1.0.4.10)

No news.

MP85A-Toolkit V.1.0 R5.8:

Only internal clearing work.

#### EASYmonitor CE V.1.1 R1.1:

No news.

#### NEW INDUSTRYmonitor (Version: 1.2.0.3)

New:

- Visu: IO-curves with light-green background.
- Different colors of the dialogs when leaving the IM (close IM store PS in no.31 to restart with same settings).

Bug-Fixes:

- Correction of Data-storage into the right sub-folders, when the INDUSTRYmonitor is started and MP85A are already storing data (curves/results); (data-storage did run in a default directory).
- Change from normal Threads to Threadpool to prevent that the PC-memory runs over (Microsoft .Net error).
- Implement IM-Process termination to get a clear closing operation for the IM without having the IM running as background-process.
- If FW delivers a negative process-status (whitch is not valuable), IM stays stabile.
- Improved Form-handling (switch from MULTImonitor to EASYmonitor and back) to prevent a PC-Memory blocking (this caused big loss of performance).
- Fmax and Fmin had wrong number of decimal points.
- IM waits for empty curve-memory in the MP85A to proved data-storage (curves/results) in 2 different directories, when switching to a new directory.
- IM uses advanced command: sdo (2950/40=suppress process-start (also from PLC)) to prevent, that parameter-set-changing collide the right entry and storage of the parameters.
- After change of Parameter set (or Fitting Point in BPM), the new evaluation-Criteria (Tol.Windows or Tol.band) gets indicated and old process-curve is deleted.

### FASTpress Suite - CD V140

#### NEW PME-Assistant (Version: 3.3.R101)

New:

- Visu: IO-curves with green background
- Improvement to Microsoft Windows7 (32bit) comparability
- Implementation of functions (FW 2.22 in the MP85A is needed!!):
  - Set dig. out to actual number of flash- parameters (binary count)
  - Set.dig.out when PS loading is ready (than MP85A is ready for next process)
  - Set Heartbeat (Watchdog) to dig. out
  - Firmware-update on MP85A can be allowed/forbidden (selectable)
  - Each process can be stored with a on R-file on memory-card or PC



- Reset/Backup of Flash parameter-sets (XML-format) to/form PC
- Clearance of IO/NIO-signals when the process is started (selectable)
   All 8 limit-switches can be selected for IO/NIO-evaluation Visu in:
- All 8 hinti-switches can be selected for 10/10/0-evaluation vis process-curve, last results, stored processes
   Eice buffer on processes
- FiFo-buffer on memory-card for process-curves/results 1.000/10.000 selectable
- Refresh-function in table for selection of stored processes

#### **Bug-Fixes:**

- Code-entry corrected for Passcode
- Sub-Menu storage to store parameter-set on PC
- Menu-correction for storing XML-parameter-sets in MP85A-flash

#### PME-Firmware Loader V1.1.4:

New:

 PME-Firmware-Loader is no longer part of the PME-Assistant, and can be installed separately from the FASTpress Suite CD.

#### NEW EASYteach (Version: 1.0.4.10)

No news.

#### MP85A-Toolkit V.1.0 R5.7:

New:

Implementation of the new function of the new MP85A firmware 2.20 to 2.22

#### EASYmonitor CE V.1.1 R1.1:

New:

 <u>New file-interface implemented</u> whitch allows modifying and re-loading devicesettings via an xml-FILE from different application (e.g. WinCC) into a connected MP85A(DP) easily.

3 new comments implemented in the EASYmonitor CE application, which are monitored each second. Default directory is "\My Documents".

- 1.) Does the EASYmonitor CE finds the command-file <u>"export.now"</u>, all actual MP85A(DP) device-settings are stored in a file "export.xml" and the command-file "export.now" gets deleted.
- 2.) Does the EASYmonitor CE finds the file <u>"import.xml"</u>, the devicesettings from this file will be imported into the MP85A(DP) and deleted after the import and the display (GUI) of the EASYmonitor CE gets an refresh.



3.) Are there files existing in the directory like <u>"save\_to.1"</u> up to <u>"save\_to.31"</u>, the actual device-settings will be stored into the corresponding Flash-parameter-set (1 ...31) of the MP85A(DP) and the command-file gets deleted afterwards.

#### **MULTImonitor**

This application is no longer available. The functions are included in the INDUSTRYmonitor !!

#### NEW INDUSTRYmonitor (Version: 1.2.0.2)

New:

- Improved Passcode selection (super user-mode) with double and hidden passcode-entry, optional the display of the passcode
- Speed-up of process-curve indication
- Visu: IO-curves with green background
- If MP85A devices are disconnected from the ETH-network, they are shown as gray button in the left device-list after acknowledge and can be reconnected in the worker-level (e.g. reconnection after drop-out of the power supply)
- Possibility for customizing text and information in the header of the Overviewand Detail-window. Control via ini-file (CustomizedControlTexts.ini) in the relevant language-submenu
- Data-storage: No Time-submenus when 1 day (1440 min.) is selected (only a new date-submenu after midnight 00:00)
- Backup-function to restore/load flash-parameter sets (XML-format) from/to PC
- Implementation of 3 Plug-Ins: SDO-Terminal, Workpiece-entry, Min.-Max.value-viewer, I-P.M-Quality Data Storage
- Improvement to Microsoft Windows7 (32bit) comparability
- Implementation of functions (FW 2.22 in the MP85A is needed!!):
  - Statistic processing ON/OFF selection
  - Set dig. out to actual number of flash-parameter set (binary count)
  - Set.dig.out when PS loading is ready (than MP85A is ready for next process)
  - Set Heartbeat (Watchdog) to dig. out
  - Firmware-update on MP85A can be allowed/forbidden (selectable)
  - Each process can be stored with a on R-file on memory-card or PC
  - Reset/Backup of Flash parameter-sets (XML-format) to/form PC
  - Clearance of IO/NIO-signals when the process is started (selectable)
  - All 8 limit-switches can be selected for IO/NIO-evaluation Visu in: process-curve, last results, stored processes
  - FiFo-buffer on memory-card for process-curves/results 1.000/10.000 selectable

**Bug-Fixes:** 



- Correction of Data-storage on the last day in the month (storage was impossible)
- Visu EASYswitch: show switch-events (triangles) only when loading curves
- Menu-correction for loading XML-(Flash)-parameter sets

FASTpress Suite - CD V139

#### NEW PME-Assistant (Version: 3.2.R701)

**Bug-Fixes**:

- Backup-function: store/load Flash-parameter-sets on PC
- Read corresponding R-file correctly if only curve-file selected
- Graphics elements for Hap tic-windows

#### PME-Firmware Loader V1.1.4:

No news.

#### NEW EASYteach (Version: 1.0.4.10)

No news.

#### MP85A-Toolkit V.1.0 R5.4:

New: Smaller updated on graphical elements

#### EASYmonitor CE V.1.1 R0.0:

No news.

#### MULTImonitor V.1.0R3.3:

No news.

#### NEW INDUSTRYmonitor (Version: 1.1.0.6)

New:

Shut-down INDUSTRYmonitor with out Microsoft-Windows comments



- Optimized graphics for fast curve-visualization
- Create new sub-directory for R/CD-files when time 00:00 is exceeded
- If option "-, is selected no time-sub-folder is created
- Curce-visu: now without any curve-history selectable
- Curve-Archive: curve-listing now with Date&Time of the curves

#### **Bug-Fixes**:

- Function "Reference Zero-Value" corrected
- IM running stabile, when after loading R-/C-/D-files

\_\_\_\_\_

FASTpress Suite - CD V138

#### NEW PME-Assistant (Version: 3.2.R601)

Bug-Fixes:

- correct texts in the table of results for the tolerance-windows
- Update of the Online-help and pdf-manuals

#### PME-Firmware Loader V1.1.4:

No news.

#### NEW EASYteach (Version: 1.0.4.10)

New:

 Implementation of the EASYteach function if the process-curves are in the quadrants Q2,Q3,Q4 of the X/Y-diagram

Bug-Fixes:

- correction of the visualization of tolerance-windows, when more processcurves are loaded after tolerance-windows are created
- correction of the visualization of the average-curve
- correction of entry/exit-visualization (arrows) of the tolerance-windows
- correction of smaller text-writing errors

#### MP85A-Toolkit V.1.0 R5.3:

No news.



#### EASYmonitor CE V.1.1 R0.0:

No news.

#### MULTImonitor V.1.0R3.3:

No news.

#### NEW INDUSTRYmonitor (Version: 1.1.0.2)

New:

- Implementation of the full EASYswitch functionality
- Extension of the adjustment-possibilities for tolerance-windows
- SDO-terminal
- Plug-In's (2 pre-defined, more possible via the customer)
- Update of the Online-Help
- Update of the pdf-manuals (available on HBMdoc and on the System-CD)

**Bug-Fixes:** 

- corrected graphics for process-curves and position of relative axis and windows
- corrected text for results of the measurement

### FASTpress Suite - CD V137


#### PME-Assistant V3.2.501:

- New: Assistant is now also running on PC/Laptop with Windows Multi-Language-Operating-System from Microsoft.
- BugFix: Assistant is checking the MP85A.. firmware and hides option whitch are not Supported by the firmware. (an info-message pops up for user info, if he has to use a newer, actual version of the PME-Assistant).

PMEAssist		×
the connected d	his program is not fully evice version. e newest availlable ver	
	ок	


New: Installation routine extended for Toolkit examples and the new INDUSTRYmonitor.





New: Expansion of the indication of the MP85A device-status.





New: - Now beside MMC also SD-memory cards (up to 2GB) can be used in the MP85A... File-transfer now also from PC to MMC/SD card. (FW.2.18 necessary) (NO SD-HC format applicable !!!)

, Files on SD/MMC	<u>a - D x</u>
MMC/SD	
AMMC_MP85_GU	
	diffuses and yorkpieces description
PC	
U:\HBM\Produkte\PME\MP85A_MP85A	OP\Tests
001_01.xml 001_02.xml	*
001_03.xml 001_04.xml	-

- Filtering of unacceptable strings: ^°!"§\$%&/(){\~+\*-.:,; for String parameters like channel name, workpiece-ID,.. etc. (FW.2.18 necessary)



1	
Target memory	External via CAN/Ethernet 💌
SD/MMC free memory (kByte	e) <mark>0</mark>
Internal free memory (Byte)	173156
Saving method	No data loss 💽
Save results	none 💌
File format	Ascii 💌
Save curves	none 💌
No. of saved curves on SD/MMC	1000
Statistical data handling	Enabled 💌
Save statistical data	
Save statistical data automatically	Disabled 💌
Workpiece name, 60 chars. (invalid:!*?/<> )	
Subdirectory	

- PME-Assistant can be automatically started with a pre-selection of Menus:
  - Set-of-menus has to be stored as a collection via the PME-Assistant.
  - Add the directory and the name of the menu-collection-file to the properties in the windows start function.
- Update of the PDF- documentation and INDUSTRYmonitor is included in the Quick-start manual of the FASTpressSuite).




#### EASYswitch (MP85A(DP)-S :

New: Multiple switch-events in a switch-evaluation window can be ignored and evaluated as OK-event. (FW.2.18 necessary)

	ð	×
switch1 off		
✓ Window active		
Consider window result in total result		
Window type		
C Monitoring window with evaluation of Min/Max		
C Monitoring window with evaluation of y-mean		
C Monitoring window with evaluation of x-mean		
🔿 y limit		
🔿 x limit		
S Block window (end window)		
Switch Control Switch Input		
Switching direction Open		
☐ Ignore chatter		
C Haptic Test Configure		

Switch-events can be sent via Profibus to the MP85ADP-S.
 (FW.2.18 necessary)
 So, beside the real switch input, there are 4 additional (virtual) switch-inputs.

#### Example:





ID:8 Digital inputs		_	
	Weg		Kraft
Zero balance	Input not assigned 💌		Input not assigned 💌
Shunt calibration	Input not assigned 💌		Input not assigned 💌
Load parameter set Bit 0*	Input not assigned 💌		Input not assigned 💌
Load parameter set Bit 1*	Input not assigned 💌		Input not assigned 💌
Load parameter set Bit 2*	Input not assigned 💌		Input not assigned 💌
Load parameter set Bit 3*	Input not assigned 💌		Input not assigned 💌
Load parameter set Bit 4*	Input not assigned 💌		Input not assigned 💌
Start/End process	Input not assigned 💌		Input not assigned 💌
Start transducer test	Input not assigned 💌		Input not assigned 💌
Clear statistics	Input not assigned 💌		Input not assigned 💌
Clear total statistics	Input not assigned 💌		Input not assigned 💌
Save statistics	Input not assigned 💌		Input not assigned 💌
Switch check 1	Input 1 📃		Input 1 💌
Switch check 2	Input 1 Virtual Input 1		Input 1 💌
Switch check 3	Virtual Input 2		Input 1
Switch check 4	Virtual Input 3		Input 1 💌
	Virtual Input 4 Input not assigned		Input 1 💌
Pevice: Station#3 ParSet: (ps1-hand-modell) [PC: bin	ı j		
–0.001 mm y 0.150 N			
/1 ● LV2 ● LV3 ● LV4 ● LV1 ● LV2 ● LV3 ● L	∨4 )		
	ST Latus		

### PME-Firmware Loader V1.1.4:

No news.

### EASYtech V1.0.4.7:

BugFix: Correction for the Reference-point calculation for curves in Q2..Q4.

#### MP85A-Toolkit V.1.0R5.1:

New: Implementation of COM-Interface COM; useable e.g. under VB6 (Visual Basic). (See Toolkit Online-Help if Toolkit is installed.)

#### EASYmonitor CE V.1.1 R0.0:

Update:\_Graphic-elements for buttons replaced, so that EASYmonitor CE runs on CE-terminals from Siemens (Siemens had changed the Windows operating system).



#### MULTImonitor V.1.0 R3.3:

New: RESTRICED-MODE - the MULTImonitor can be started with the option, that the user can't close the application. With this Unser/worker can not stop data-storage on a target PC in production.


#### INDUSTRYmonitor V.1.0R0.3:

New: First Release of the Production-Software INDUSTRYmonitor for Windows2000 / XP / Vista. Operating System running on IPC-Computers.

Optimized for touch-operation with max. 12 MP85A(DP)(-S) devices.

MMC/SD card necessary: Parameter sets only to be stored and used from MMC/SD cards in this first version !

The INDUSTRYmonitor can be installed in a demo-mode to be started 25 times. After started 25 times the Software will not connect to any MP85A.. device (only visualization of saved processes is possible). To get unlimited access, the INDUSTRYmonitor can be registered with a MP85A-Runtime license during the installation (see also price list).



Each page of the INDUSTRYmonitor has a Help-Button with dedicated Help informations to the functions of the page



### FASTpress Suite - CD V136


#### PME-Assistant V3.2.401:

New: Option for Tolerance-windows: active - after process has left the former window (needs MP85A firmware 2.15b or higher).

-Window options

- Evaluate window in real time (online window)
- Consider window sequence for this window
  - Activate next window on entering current window
  - O Activate next window on leaving current window.

New: IO / NIO –Counter can be reseted with "clear statistics" (needs MP85A firmware 2.15b or higher).




New: Retrieve saved data / curve now also from toleranceband and envelope curves (needs MP85A firmware 2.15b or higher).



📳 ID:5 🛛 Rel	trieve	saved data								<u>_ 0 ×</u>
		Process counter:	•	0005 💽	Proces Curve	s Data File: Files:		_15000005_0 15000005_0		Device Name: PressFit FWV2.15
Process							Evaluation M			-
		42.00.00	08/11:59:	001	120 120	w				
Date of creat				.03!	Rangew	ile dow				
Workpiece ID		Tolband-			100-2-1					
Parameter se	et:	15 (PS15	5 Hüllkurv	/e-Ha)						
- Total Result-					ETTT					
Cause for en	od: E	xternal								
Cause for all										
Cause for an	arni				<b>**</b> ******		· <del>:</del> · · · · · · · · · · · · · · · · · · ·	÷÷		
- Total result-					E 111	·	/1			
		NU.			<b>.</b>		÷			
		NIO			l i L L					
					-20-4	-+				
							• •	, xtri 🗋	20	
		Min(y)		м	ax(y)	м	n(x)		fax(x)	Mean/Sw <sup>4</sup>
F	Result	х у		×	unor) V	×	u(n) Y	×		NICON/SW
		0.235000 1.			-		,		· ·	
			008000	1.664000	8.532000	0.230000	1.008000	5,990000	8,168000	
Range window				1,004000	8,532000	0,235000	1,000000	3,330000	0,100000	
window -				1,004000	8,532000	0,230000	1,000000	3,330000	6,160000	
window Select file				1,004000	8,532000	0,230000	1,000000	3,330000	0,100000	
window Select file Filter files Dire	ectory	U:\\HB	IM\Produl		8,532000 P85A_MP85AI					
window Select file Filter files Dire Use sub	o directo	U:\HB	IM\Produl	kte\PME\M	P85A_MP85AI	DP\Tests\mit	_FW_V2.15b	\Test-Hüllki	urve\	×
window Select file Filter files Dire Use sub	o directo	U:\\HB	IM\Produl	kte\PME\M	P85A_MP85AI	DP\Tests\mi		\Test-Hüllki	urve\	
window Select file Filter files Dire Use sub	o directo tically sl	U:\HB	IM\Produl	kte\PME\M	P85A_MP85A curve Tin ]	DP\Tests\mil	FW_V2.15b	ATest-Hüllkı	urve\ To	12.09.2008 ¥ 12.09.2008 ¥
window Filter files Filter files Use sub Automat	o directo tically sl	U:\HB ories for file search how curve and res	IM\Produl	kte\PME\M n choosing a	P85A_MP85A curve Tin ]	DP\Tests\mit	FW_V2.15b	ATest-Hüllkı	urve\ To	12.09.2008 ¥
window Select file Filter files Dire Dire Use sub Automat File type:	o directo tically sl ress:	U:\HB ories for file search how curve and res	IM\Produl	kte\PME\M n choosing a	P85A_MP85A curve Tin ]	DP\Tests\mil	FW_V2.15b	ATest-Hüllkı	urve\ To	12.09.2008 ¥ 12.09.2008 ¥
window Select file Filter files Use sub Automat File type: Device addr	o directo tically sl ress: et:	U:\HB ories for file search how curve and res	IM\Produl sults wher	kte\PME\M n choosing a	P85A_MP85A curve Tin ]	DP\Tests\mil	FW_V2.15b	ATest-Hüllkı	urve\ from to f	X X2.09.2008 X2
window Select file Filter files □ Use sub ✓ Automat File type: Device addr Parameter so Workpiece I File	o directo tically sl ress: et: ID:	U:\HB ories for file search how curve and res All files	IM\Produl sults wher any any Date	kte\PME\M	P85A_MP85A    curve Tin         Size (Byte)	DP\Tests\mil ne period: [e Process num   Sta	:_FW_V2.15b any ber: to	ATest-Hüillku	urve\ from to f from from from from from from from from	X X2.09.2008 X2
window Select file Filter files □ Use sub I H I H I H I H I H I H I H I H	o directo tically sl ress: et: ID: st_010	U:\HB ories for file search how curve and res All files	IM\Produl sults wher any any Date	kte\PME\M n choosing a v v v v	P854_MP85A curve Tin ] ] [ Size (Byte) 2273	DP\Tests\mil ne period: Process num	FW_V2.15b any ber: to stus Pa K 1	ATest-Hüllku	urve\ ↓ from [ to ] fr Sear Process 5	12.09.2008 ▼ 12.09.2008 ▼ om 939393 sh
window Select file Filter files □ Use sub I Use su	o directo tically sl ress: et: ID: st_010	U:\HB ories for file search how curve and res All files	IM\Produl sults wher any any Date 2008	kte\PME\M	P854_MP85A curve Tin ] ] Size (Byte) 2273	DP\Tests\mil ne period: [e Process num   Sta	FW_V2.15b any ber: to stus Pa K 1	ATest-Hüllkr	urve\ ▼ from to fi Bear Process 5 6	22.09.2008 ¥ 32.09.2008 ¥ om 999999 sh
window Select file Filter files □ Use sub I Automat File type: Device addr Parameter st Workpiece I File Hüllkurve tes Hüllkurve tes	o directo tically sl ress: et: ID: st_010 st_010	U:\HB ories for file search how curve and res All files	IM\Produl sults wher any any Date 2000	kte\PME\M	P854_MP854    curve Tin   	DP\Tests\mil ne period: Process num	r_FW_V2.15b any ber: to tus Pa K 1 1	ATest-Hüllkr	urve\ ↓ from [ to ] fr Sear Process 5	12.09.2008 ▼ 12.09.2008 ▼ om 939393 sh
window Select file Filter files □ Use sub I Automat File type: Device addr Parameter st Workpiece I Hülkurve tes Hülkurve tes Hülkurve tes	b directo tically sl ress: et: ID: st_010 st_010 st_010 st_010	U:\HB ories for file search how curve and res All files 00005_010.085 00006_010.085	IM\Produl sults wher any Date 2008 2008	kte\PME\M n choosing a y v y 3-05-29 15 3-05-29 15	P85A_MP85A curve Tin ] ] Size (Byte) 2273 2414 2242	DP\Tests\mil ne period: Process num Sta NO OK	r_FW_V2.15b any ber: to tus Pa K 1 1 1	NT est-Hüllkr	urve\ ▼ from to fi Bear Process 5 6	12.09.2008 ▼ 12.09.2008 ▼ om 939393 sh

New: Expansion of the indication of the MP85A device-status.



- Update of the Online-help files for the MP85A and the PME-modules.

- Update of the PDF- documentation.



#### PME-Firmware Loader V1.1.4:

No news.

#### EASYtech V1.0.4.5:

No news.


#### MP85A-Toolkit V.1.0 R3.2:

No news.

### FASTpress Suite - CD V135

#### PME-Assistant V3.2.301:

New: Tolerance-windows can be selected for integration in the total-result (IO / NIO). These windows then may be used for tool-fault detection, whitch are not relevant for the Process-result (needs MP85A firmware 2.15b or higher).



<u>New:</u> Process-Statistics can be switched ON / OFF for causes of service and set-up the system (needs MP85A firmware 2.15b or higher).

ID:5 Data storage*	
Target memory	External via CAN/Ethernet
MMC free memory (kByte)	500600
Internal free memory (Byte)	173156
Saving method	No data loss 💌
Save results	NOK + OK
File format	Ascii 💌
Save curves	NOK + OK 💌
No. of saved curves on MMC	1000 💌
Statistical data handling	Enabled 🗹 🔿
	A state of the second



<u>New:</u> Digital output for reset of a connected piezoelectric amplifier (e.g. CMA, Kistler,..). (needs MP85A firmware 2.15b or higher and hardware 1.07 or higher).

Output 4	Reset Piezosensor 💌
Switching logic	Transducer test result channel X
	Reset Piezosensor

#### PME-Firmware Loader V1.1.4:

No news.

#### EASYtech V1.0.4.5:

<u>New:</u> When creating an Envelope-curve, the beginning and end of the envelope curve gets a shift of 5% in x direction.

BugFix: additional imported process curves now get adjusted correctly to the reference point.


#### MP85A-Toolkit V.1.0 R3.2:

No news.

### FASTpress Suite - CD V134


#### PME-Assistant V3.2.201:

New: Implementation of the Hap tic-Functionality for the MP85A(DP)-S :



- New menu for setting up the Hap tic-Windows:





#### - Expansion or the table for Last results/stored results:

😼 ID:8 🛛 Results of	f last measi	urement								_ 🗆 ×
Device: EASYswitch 9	Station	ParSet: 3 (p	sModT20-2_	3p_H)						
Overall status last pro     Process counter:     Parameter set numb	2080	i i	Cause for end Cause for ala Dverall resu	rm:	ettling time e - JK	expired			auto refres	h
	Result	Min(Ch x	iannel y) y	Max(Ch x	annely) y	Min(Ch x	annel x) y	Max(Cl x	hannel x) y	Mea_
Range window		118,4	-0,113	139,7	0,186	12,2	0,091	139,7	0,186	
switch2 on (Switch)	OK						-		-	72
switch 2 off (Switch)	OK		•		•		-	-	-	104
switch3 on (Switch)	OK						-		-	118
switch3 off (Switch)	OK	-			-	-	-		-	119
Haptic_s1on (Haptic)	OK	27,7	-0,042	21,5	0,105	17,2	0,095	33	-0,023	
Haptic_s1off (Haptic)	OK	42,5	0,003	57,7	0,129	42,5	0,003	57,7	0,129	
•										
-										
Haptic Window	Haptic Resul	It Actuation	n Force Fa	Reverse	Force Fr	Difference	Force Fa-Fr	Difference Dis	placement Sr-Sa	Force-D
Haptic_s1on (Switch)	Haptic OK	0,	105	-0,	D42	0,1	147	6	6,2	
Haptic_s1off (Switch)	Haptic OK		0	0,0	)03	0,1	126	-1	5,2	

- Indication of the source of the loaded parameter-set in the headline of the graphical windows (evaluation criteria / measurement curve / firmware 2.14 or higher necessary).

- Mask: stored results/curves optimized for protocol print-outs:

🗐 ID:7 Retrieve sa								_ 0	×
	rocess counter:	00757		Process Data Curve Files:		66_004.R85 7_004.D85		Device Name My Project	2:
<ul> <li>Process</li> <li>Date of creation:</li> <li>Workpiece ID:</li> <li>Parameter set:</li> </ul>		07/16:32:50! and-modell)				5-6			
Total Result Cause for end: X reverse motion Cause for alarm:					2-boyda te lymi	EHR2	<u> </u>		
- Total result	NIO		·z				- <del>1 - 1 - 1 - 1 - 1</del>		
	Result	Mir x	(v) y	Ma x	x(y) y	Mir x	h(x) y	Max() x	1 بر
Range window		2,169000	5,222000	17,292999	92,825996	2,169000	5,222000	17,292999	9
1-start	OK	2,674000	6,345000	3,446000	7,926000	-		-	•
2-border	OK			-		-		-	•
3-rel y mittel F (rel.)	OK	8,287000	3,699000	10,065000	6,961000	-	-	-	-
4-rel x (rel.)	OK	2,799000	24,947001	5,368000	29,820000	-	•	-	•
5-block (rel.)	Error Max, y	7,684000	33,717999	7,738000	79,176003	-	-	-	•
-									
-									
•								ļ	•



- New TAB for Envelope-curve with readjusting of existing envelope-curve:

Control settings	Alarm window	Range window	Tolerance wind	ow Tolerance band	Envelope	
Modify the alre	ady existing enve h and then transf	elope				
			Apply			

#### PME-Firmware Loader V1.1.4:

No news.

#### EASYtech V1.0.4.2:

New: Storage and reload of all settings, evaluation criteria and adjustments in a project.

#### MP85A-Toolkit V.1.0 R3.2:

No news.

### FASTpress Suite - CD V133

#### PME-Assistant V3.2.101:

New:

- Indication of process-status and error-messages in a new window "status-overview".

MID:4 Display current values		×
× HW Ovfl	y HW Ovfl	
	LV1 🔵 LV2 🔵 LV3 🔵 LV4 (	9
Status Digital I/Os Outputs: Inputs:		]
🖥 ID:4 🛛 Status Overview		<u>×</u>
Measuring Status	Process Status startet running stopped ready Result valid	Process Status 2     Allocating RAM     Saving files     Setting time ongoing
Limit value 3 Limit value 4 Sceling Error EEPROM Error Flash Error Initial Calibration Error	🔵 Overall result: OK	MMC: not in use



- Retrieve saved data: clicking on a curve-file brings now curve plus results and windows in the graphic.

- Better Data Storage mechanism: checking if no files with 0kB size are produced.

- Scaling on the range-window in the graphical curve-windows.

- Tolerance-band can be modified also after it's shifted into the MP85A.

- Option in the file "Options.ini": PROGRAMCONTROL -> NEW\_FILE\_ON\_WP\_CHANGE=1/0 controls if a new R-file will be created during the change of the workpiece-id.

- New icons for "start" and "stop" by hand.

- Detailed indication of information (type/target) of the used parameter-sets.

- During a measurement-process no changes of tolerance-windows / band conditions are available.

- Information-window if no data-storage of (curves/results) in the target PC is possible.

- Retrieve saved data: Integration of a logo into this window (also availabel during the print out later on).

- Implementation of indication and adjustements the EASYswitch functions. These functions get only displayed, when an EASYswitch device is connected!

- Update of the Offline-versions for FASTpress and EASYswitch devices.

- Update of the Help-files.

- New and helpful section for FAQ's.

New (firmware 2.12 or higher necessary):

- Storage of 999 parameter-set on the additional MMC-card in binary format.

- Implementation of the condition for the end of a process-measurement.

(now selectable from an external signal or several internal conditions.

BugFix: Selection of the storage directory now ok.

BugFix (firmware 2.12 or higher necessary):

- Date correction of the curve- and result-files during coping from MMC to PC (the date of creation is fix now).

#### PME-Firmware Loader V1.1.4:

BugFix:

Renaming of the loader Software to PmeUpd.exe, because of Windows-Vista requirements.
Correct indication and storage of the selected directory in the application, using the software in a network.

\*\*\*PME-Firmware-Loader is part of the PME-Assistant, and will be installed automatically during the PME-Assistant installation.\*\*\*

#### EASYtech V1.0.3.2:

- Start of the EASYteach application now also separately possible.

- EASYteach icon now on the desktop during installation.

- Coordinates of the cursor (channel x / y) now as figures permanently available.

- New adjustements: curves can be activated / deactivated for the calculation and switched to visibal/ unvisibal (but still under calculation).

- Update of the Help-files.

\*\*\*Please order the FASTpress Suite-CD to get the latest Software and Applications.\*\*\*

#### MP85A-Toolkit V.1.0 R3.2:

New:

- Application: MULTImonitor.exe (Up to 32 MP85A(DP connected to the application) now also available in german language. Application running under Microsoft Windows2000 / XP / Vista. - Implementation of the EASYswitch (MP85A-S / MP85ADP-S) functions.

- More detailed and better Help-description.

-----

### FASTpress Suite - CD V132

#### PME-Assistant V3.1.401:

New:

- Indication of the Message-window for "missing communication" to be activated / deactivated by mouse-click.

BugFix:

- Time-Out for "checking of a missing communication" expands up app. 10 sec.
- Filename gets the correct name with the Workpiece-ID, whitch fits to the actual process.

#### PME-Firmware Loader V1.1.0:

BugFix:

Correct indication and storage of the selected directory in the application, when the

#### EASYtech V1.0.2.0:

No changes

#### MP85A-Toolkit V.1.0 R3:

New:

New Application: **MULTImonitor.exe** (Up to 32 MP85A(DP) can be connected to the application. Max 4 station can be displayed on the Screen). Application running under Microsoft Windows2000 / XP / Vista

New Application: **EASYmonitor CE**. An Installation witch transmits the Application to a Terminal whitch runs under Microsoft WindowsCE 5 or higher.

\*\*\*Both applications can be started 25 times (demo modus). Afterwards a Runtime-license is necessary.\*\*\*



### FASTpress Suite - CD V131

#### PME-Assistant V3.1.301:

New:

- Automatic Registration and indication of Interface-timeouts (loosing connection and getting connection back)

- Expanding the change. log file for registration of changing's, done via PME-Assistant
- Visual Background informations in the PME Assistant (picture / animation /webpage)

- Curve history in the measuring mode up 100 curves maximum

- Message in a connection to an already connected device should be opened

-Retrieve saved data/curves: selecting curves by mouse-click open curves in addition the results, windows, etc.

#### EASYtech V1.0.2.0:

New:

- Better handling of the functions and graphics

**BugFix:** 

- Re-Import of the tolerance-windows from EASYteach to MP85A(DP9 now with correct coordinates and relative y-point

#### MP85A-Toolkit V.1.0 R2:

New:

- New graphical objects with correct licenses implemented
- Update of the help files
- Update of EASYmonitor application example



#### \_\_\_\_\_

Please always use the latest firmware and software version, available on HBM.com's download section:  $\rightarrow$  Support  $\rightarrow$  Software / Firmware Downloads  $\rightarrow$  Industrial amplifier

-- end of file



#### **HBM GmbH**

www.hbm.com Email: info@hbm.com Tel. +49 6151 803-0 Fax +49 6151 803-9100



measure and predict with confidence